

Lane Departure Warning System (LDWS)

Alerts the driver if the vehicle unintentionally leaves its lane without the turn indicators activated.

