

Lane Departure Warning System (LDWS)

Warns the inattentive driver of the departure of the vehicle from the lane when turn indicators are not activated.

